

CZ Obsah balení (E) Pakendi sisu (E) Περιεχόμενα
 HU Tartalom (V) Saturs (T) Turinys (L) Zawartość
 CO Contintut (SK) Obsah (F) İçindekiler (U) Зміст



x1



x1



x2



x2


CR2032




x1



x2






x1



x1




x2




x1



x1



3x AA/LR6



30mm






x1



x1



CR2032



15mm









CZ Úvodem (E) Παράρτημα (U) Kezdő lépések (V) Darba sajkása (T) Darbo pradžia
 L Przygotowanie do użycia (U) Notturni de bază (SK) Začínáme (F) Kurulum (U) 3 чоро поспрачати

- 🇨🇿 Volitelné funkce ⑬ Lisavõimatused ④R Προαιρετικές λειτουργίες ④D Oracionális funkciók
- ④V Papildus funkcijas ④ Papildomos funkcijos ④Funkcje dodatkowe ④D Charakteristické optionálne
- ④S Volitelné funkce ④ Opsiyonel özellikler ④D Dört seçeneği






	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
🎵 x4	•	•					•	•
🎵 x6	•	•	•	•			•	•
🎵 x8	•	•	•	•	•	•	•	•



🔊 x2	3Hrs	🔊 x3	6Hrs
🔊 x4	9Hrs	🔊 x5	12Hrs

- 🇨🇿 Párování ③ Sídumine ④ Zvířel
- ④D Összehangolás ④ Szasatistásna ④ Priríšimas
- ④P Navigazione połączenia ④ Conexiune
- ④S Párovanie ④ Eşleştime ④D Прив'язування



- 🇨🇿 Odstranění poruch ③ Kui vajad lisa abi ④R Επίλυση προβλημάτων ④D Hibakeresés
- ④V Problēmu novēršana ④ Gedimo paieška ④P Usuwanie usterek ④D Depanare
- ④S Riešenie problémov ④ Destek ④D Пошук та усунення несправностей

livewell.honeywell.com

