





Electrolux

Ease C2




1


* Certain models only | Suivant les modèles | فقط بعض الموديلات | Само определени модели | Pouze u některých modelů | Nur bestimmte Modelle
 Kun på visse modeller | Ainult kindlad mudelid | Solo algunos modelos | فقط برای بعضی مدلها | Vain tietyt mallit | Ορισμένα μόνο μοντέλα
 Samo određeni modeli | Csak egyes típusoknál | Solo per alcuni modelli | Tik tam tikriems modeliams | Tikai noteiktiem modeļiem | Kun enkelte modeller
 Tylko niektóre modele | Doar pentru anumite modele | Только отдельные модели | Bara vissa modeller | Le določeni modeli | Len určité modely
 Само код одређених модела | Yalnızca bazı modellerde | Залежно від моделі





2




3



4




5




6





R Recommended nozzle | Brosse recommandée | الفرقة الموصى بها | Препоръчителна дюза | Doručovaná hubice | Empfohlene Düse | Anbefalet mundstykke
 Soovituslik otsak | Cepillo recomendado | نازلهاى توصيه شده | Suositeltava suulake | Συνιστώμενο ακροφύσιο | Preporučeni nastavak | Ajánlott szívófej
 Spazzola consigliata | Rekomenduojamas antgalis | Leteicams uzgalis | Anbefalt munnstykke | Zalecana dysza | Perie recomandată | Рекомендованная насадка
 Rekomenderat munstykke | Priporočni nastavek | Odporučaná hubica | Препоручени наставак | Önerilen başlık | Рекомендована насадка



7



8



9



www.electrolux.com/shop